



Taurus Series Multimedia Players



Quick Start Guide

01 Introduction

The Taurus series products are multimedia players created for full-color LED displays. The Taurus series multimedia players integrate playback and sending capabilities, allowing users to publish content and control LED displays with a computer, mobile phone or tablet. Working with our superior cloud-based publishing and monitoring platform, the Taurus enables users to manage LED displays from an Internet-connected device anywhere, anytime.

02 Required Software


The typical connections and login of the Taurus series products require the following software: ViPlex Handy, ViPlex Express and NovaLCT.

Software	Operating System	Download
ViPlex Handy	Android	
	iOS	
ViPlex Express	Windows	https://www.vnnox.com/download
NovaLCT	Windows	

1


03 Typical Connections

Ethernet Cable



Required configuration:
In ViPlex Express, turn on DHCP service.

Wired LAN



Required configuration:
Make sure the DHCP service in ViPlex Express is turned off and set up the computer to obtain an IP address automatically.

Wi-Fi AP

The Taurus series products come with Wi-Fi AP. The default SSID is "AP+Last 8 digits of the SN" (for example: AP10000033). The default password is printed on the SSID label.



No configuration required.

Wireless LAN

This connection method is available for products that support Wi-Fi Sta.



Required configuration:
In ViPlex Express, log in to the Taurus and connect to the Wi-Fi AP of the router.

2

04 Login

After hardware connection, log in to the Taurus with the software to configure screens, publish content, upgrade firmware, and bind the Taurus to the cloud platform.

The login user name is "admin". The default password is "SN2008@+". You are advised to change the default password to enhance information security.

Note:

For more information about the software, please see their user manuals. You can also scan the QR code on the product to view the online help for ViPlex Handy.

Log In to Taurus with ViPlex Handy

Step 1 Open ViPlex Handy and go to the **Local Devices** page.

ViPlex Handy can automatically detect the Taurus and refresh the local device list. You can also swipe down to manually refresh the local device list.

: The Taurus is online and you can log in to it. Go to Step 2.

: The Taurus is offline and you cannot log in to it.

Step 2 Tap **Connect** next to a device name.

Step 3 Enter the password for the "admin" user and tap **OK**.

Upon successful login, is displayed and ViPlex Handy automatically saves the account information.

3

Log In to Taurus with ViPlex Express

Step 1 Open ViPlex Express and go to the **Terminals** page.

Step 2 Click **Refresh** to refresh the device list.

After detecting the Taurus, ViPlex Express will try to log in to the Taurus with the default account or the account used for last login.

: The Taurus is online and you can log in to it. Go to Step 3.

: The Taurus is offline and you cannot log in to it.

: You have successfully logged in to the Taurus.

Step 3 Click **Connect** next to the Taurus information.

Step 4 Enter the password for the "admin" user and click **OK**.

Upon successful login, ViPlex Express automatically saves the account information.

Log In to Taurus with NovaLCT

Step 1 Open NovaLCT.

Step 2 From the menu bar, choose **User > Media Player Login**.

Step 3 In the **Terminal List** dialog box, click **Refresh**.

Step 4 Select a Taurus device and click **Connect System**.

Step 5 Enter the user name and password, then click **OK**.

Upon successful login, the monitoring information of the Taurus is displayed on the main window of NovaLCT.

4

[Official Website](http://www.novastar.tech)
www.novastar.tech

[Technical Support](mailto:support@novastar.tech)
support@novastar.tech